





Manual is for the following models: G-7F G-7FB GCG-7F GCG-7FB GCG-7F2 GCG-7-FB31N* G-7-FB31N* G-7-FB31N * G-7-F31N*

Instruction Manual



FOR YOUR FUTURE REFERENCE

- inside of your cooler.
- Keep your receipt with this manual for future warranty service.

Model #: _____

Serial #: _____

Date of Purchase: _____

Manual is for the following models: G-7F G-7FB GCG-7F GCG-7FB GCG-7F2 GCG-7-FB31N* GCG-7-F31N* G-7-FB31N * G-7-F31N* GCG-7-F231N*

Instruction Manual



G-7f/GCG-7f

This easy-to-use manual will guide you in getting the best use of your cooler.
Remember to record the model number and the serial number. This information can be found on the

TABLE OF CONTENTS

Parts & Identification	3
Safety Precautions	4
Features	5
Instructions	5
Flammable R290 Warnings	5
Ambient Environment	5
Preparation Before Operation	6
Replacing the Interior Light	7
Replacing the Door LED Lights	8
Setting Up Power Cord Holder	8
Startup, Operation & Temperature Adjustment	9
Repair & Maintenance for Refrigeration Drawer	9
Maintenance	10
Cleaning Shutdown Questions & Answers	10
Reversible Door Exchange	
Troubleshooting	13
After-Sales Service	13
G-7f/GCG7f Circuit Diagram	14
G-7f Electrical Wiring Diagram	
GCG-7f Electrical Wiring Diagram	

PARTS & IDENTIFICATION



- Door Handle
- Glass Door Complete (2)
- LED Light in the Glass Door
- LED Light Cover
- Door Gasket
- Door Limiter
- Door Self-Closing Rod
- Fan Guard
- Fan Baseboard
- Evaporator Fan 10
- LED Light 11
- 12. LED Light Cover
- 13. Pilaster Strips (long, 2)
- 14. Large Shelf (2)

- Small Shelf 15.
- Pilaster Clips (12) 16.
- Pilaster Strips (middle, 2) 17.
- 18. Pilaster Strips (short, 2)
- 19. Return Pipe
- 20. Evaporator
- Air Channel Panel 21.
- Thermostat panel (5) 22
- Thermostat (20) 23
- 24. Top Hinge (4)
- 25. Cabinet
- 26. Electric Box Housing
- 27. Light Switch (2)
- 28. Switch Panel

- Switching Power Supply of LED Box (2)
- 30. Bumper Block (2)
- 31. Compressor Guard
- 32. Power Cord
- 33. Compressor
- 34. Drip Pan
- 35.

- 43. Lower Right Hinge 44. Lower Left Hinge
- 45. Leveler (2)
- 46. Fixed Caster (2)

- 1. Glass door removed.
- 2. Shelves kept in place in order to prevent any small child from climbing inside cooler.
- technician:
- 2. To remove the compressor or remove the oil from the compressor

This appliance uses flammable insulation blowing gas, please dispose of the appliance according to the local regulation. The distributor/retailer can contact their local metal recycling center to pick up the remaining cabinet, shelves, etc. By law, disposal of hazardous wastes may be subject to fines and imprisonment under the privisions of the environmental regulations.



SAFETY PRECAUTIONS

When using this appliance, always follow the basic safety precautions:

- 1. This appliance is intended for commercial only or similar use.
- 2. DO NOT use the appliance outside. For indoor use only
- 3. DO NOT use jet/pressure washers to clean this appliance.
- 4. DO NOT allow children to play with the packaging, and destroy plastic bags safely.
- 5. Always switch off and disconnect the power supply to the unit before cleaning.
- persons in order to avoid a hazard.
- concerning use of the appliance by a person responsible for their safety.
- 8. Children should be supervised to ensure that they do not play with this appliance.

- 11. Keep the appliance and its cord out of reach of children less than 8 years of age.

- 1. To recover all Freon/refrigerant from the cooler

3

- Connecting Tube for Condenser
- Condenser Fan 36.
- 37. Condenser
- Compressor Baseboard 38.
- 39. Filter Dryer
- **Connecting Tube for Filter Dryer**
- 42. Lower Left Hinge Cover

- 40
- 41 Lower Right Hinge Cover

G-7f/GCG-7f

6. If the power cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified

7. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction

9. This appliance can be used by children age 8 years and above; and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be preformed by children without supervision.

10. The appliances are not intended to be operated by means of an external timer or separate remote-control system.

12. Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

Please save these instructions!

DANGER! Proper Disposal of the Refrigerator

PRE-CAUTION, NON-OPERATING COOLERS SHOULD HAVE:

FOR PROPER DISPOSAL OF COOLER: Distributors / retailers need to contact a qualified service

FEATURES

- Designed with an elegant shape and quick refrigeration speed, this commercial-grade product is an ideal choice for shopping malls, supermarkets, hotels, etc.
- Transparent glass doors are built with hollow, toughened glass that provides a high level of heat insulation. Clear doors allow for high product visibility.
- The forced air system allows for fast cooling speeds, which helps maintain a consistent temperature.
- Adjustable shelves allow for a wide variety of products to be stocked. •
- A built-in lock offers the ability to secure products.
- The refrigeration unit is designed for easy access, allowing for fast and simple repairs. ۲
- This equipment is intended for storage and display of non-hazardous packaged product. ٠



CAUTION FLAMMABLE REFRIGERANT

- WARNING Keep clear of obstruction all ventilation openings in the appliance enclosure or in the structure for building-in.
- WARNING Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- DO NOT damage the refrigerant circuit..
- DO NOT use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

INSTRUCTIONS

Ambient Environment

- Place cooler on an even surface to reduce vibration and noise.
- To transport, do not tilt the cooler beyond a 45 degree angle. •
- Do not place cooler in direct sunlight or near any heat sources.
- Do not place cooler in environment temperatures that exceed 86°F.
- Do not place cooler in below normal temperatures.
- Do not place cooler in extreme humid environments, this may cause components to rust.
- Do not place cooler near constant running or splattering water, this may cause immediate damage to refrigeration system.
- Must allow at least 4" between rear of cooler and wall for proper ventilation and heat dissipation of cooler.
- Do not place furniture or other articles with sharp edges near the cooler in order to prevent damage to the glass door.

PREPARATION PRIOR TO OPERATION

- Remove all packaging materials before using cooler. This includes: foam pedestal, adhesive tape (used to fix accessories) and protective gaskets.
- Inspect cooler for concealed damage. Immediately file a claim with the freight carrier if there is damage. IDW is not responsible for damage incurred during shipping.
- For proper operation, place the cooler on a dry, level surface.
- Clean the interior surface with a soft cloth and lukewarm water before operation.
- Keep cooler in an upright position for 30 minutes prior to use.
- IDW requires that a sole use circuit be dedicated for the unit. Failure to do so voids warranty. WARNING: Do not use extension cords. WARNING: Compressor warranties are void if compressor burns out due to low voltage. **WARNING:** Power supply cord should not be removed or altered in any way.

Leveling

- **WARNING:** Warranty is void if ventilation is insufficient.
- door operation will be affected by leveling.
- Ensure that drain hose or hoses are positioned in the pan.
- Remove plug and cord from inside the lower rear of the cooler.
- The unit should be placed close enough to the electrical supply so that extension cords are never used.

(Maximum load for big shelf is 24kg, Maximum load for small shelf is 15kg)

Display refrigerators can be loaded within the shelf dimensions from the front to back side. They can also be loaded in any space from the bottom to the top interior cabinet. Do not allow product to block the evaporator fan cover because the evaporator fan helps the cooler to ventilate properly.

Shelving Installation





G-7f/GCG-7f

Set unit in its final location, making certain there is adequate ventilation in the room.

Proper leveling of the G-7f/GCG-7f cooler is critical to it operating correctly. Condensation removal and

< The cooler should be leveled front to back and side to side with a level.

• Securely insert shelf clips into pilasters

• Shelf clips should be level so shelf lays flat



Place shelf on shelf clips

REPLACING THE DOOR LED LIGHTS

REPLACING THE INTERIOR LIGHT



1 Using a small flathead, pry up the plastic cover.



2 Disconnect the lights.



3 Unscrew (3) screws using a Phillip's screwdriver.



5 To install LED lights follow the above directions in reverse order.





the Cooler.

G-7f/GCG-7f

1 Take out the two Spacers and screws supplied in the Accessory Pack shipped with

2 Use a Phillips screwdriver to secure the two Spacers onto the rear of the cooler.

STARTUP, OPERATION AND TEMPERATURE ADJUSTMENT Operation

• Prior to stocking cooler with product, it should be operated empty for half an hour.

Temperature Adjustment

• G7f/GCG-7f performance testing position of the thermostat is around 4.5-6.



REPAIR AND MAINTENANCE FOR REFRIGERATION DRAWER

* A CERTIFIED TECHNICIAN IS REQUIRED TO REPAIR ALL REFRIGERATION COMPONENTS FOR WARRANTY PURPOSES.



For convenient repair, the refrigeration components (compressor, condenser, condenser fan and filter) are designed using a split system; any component can be easily replaced. Replacement procedure is as follows:



- Unplug the unit.
- 2 Remove the screws from the back grill, and then remove the grill.



3 Unplug all connections and terminals that are in need of repair.





or repair.



- (shown right).
- procedure.

MAINTENANCE - Cleaning Shutdown Questions and Answers

Cleaning and Maintenance

- **1** Unplug the cooler before cleaning.

- 4

If the cooler's power will be off for a long period of time, unplug it, clean as instructed above, and keep door open until dry.



9

G-7f/GCG-7f

4 Using a screwdriver, remove the (3) screws from the refrigeration drawer base plate.

5 Slide the Refrigeration Drawer out to easily access refrigeration components. Remove the component to replace

6 Using plastic bristle brush, carefully clean the coil being aware that fins can be bent or be damaged if too much force is used

7 After repair or maintainence, re-install all parts using the reverse

2 Use a soft cloth or sponge with water or soap (non-corrosive mild detergent), while cleaning.

After cleaning, wipe the cooler using dry cloth to keep the cooler from rusting.

3 Do not spray water on the cooler, and do not use hard or steel brushes to clean the cooler.

Do not use organic solvents, boiling water, washing powder or acid while cleaning.

DOOR REVERSAL (For G-7f Coolers Only)



1 Remove the plastic cover on the bottom hinge, disconnect the terminals and then hide the terminals in the door's reserved hole.



- **2** Remove the right upper hinge, then remove the door.
 - 3 Take out the torsion rod from the upper right of the door.
 - 4 Pull out the wiring from door's reserved hole, the wiring stretches out from the upper right of door.
 - **5** Insert the torsion rod into corresponding holes on bottom right of the door.
 - **6** Rotate the door clockwise 180°, so the wiring is stretched out from the bottom left of the door.

7 Remove the hinge axis from the right bottom hinge, insert it into the left bottom hinge.

DOOR REVERSAL Cont. (For G-7f Coolers Only)



8 Feed the wiring terminals through the hinge and connect the terminals.













180°



G-7f/GCG-7f

9 Reinstall the torsion rod into the new position of the door axis.

10 Set the upper hinge into the torsion rod at approximately a 60° angle. Rotate the hinge to the right counterclockwise aligning the holes in the bracket with the holes on top of the cabinet.

11 Install the limiter on the door. Installing sequence the washer-gasket-limit-bolt.

12 Check to ensure the door is securely attached and functioning properly.

TROUBLESHOOTING

The following are not Malfunctions:

Issues	Solutions		
Liquid flowing noise within cooler	This liquid is the sound of the cooling agent flowing through the pipes.		
Refrigeration system is shutdown for longer periods of time while temperature inside is still very low.	This refrigerator has a strong level of heat preservation and can main- tain a relatively ambient temperature.		
Condensation on glass door	This may be due to a high indoor humidity or a low inside temperature value may be set. Wipe the door dry with a towel.		

- 1 This refrigerator has been designed and manufactured according to National standards. If there are any questions during use, refer to this operation manual to help troubleshoot problems.
- 2 When disposing of the cooler, please remove the door and lock assembly to avoid children accidentally becoming trapped inside the cooler.

AFTER SALES SERVICE

Any product has the possibility of malfunction. Please observe the cooler's operation and any changes to product being stored. If there are any abnormal cases, refer to the table below. If there is still no change after following the below instructions, please inform our service center in a timely manner to avoid a further loss of the unit.

lssues	Solutions		
Cooler is not functioning.	 Please check power supply: Fuse damage The plug is not securely inserted into the wall socket Check for low voltage 		
Cooler is not keeping product cool.	 Provide ample space between all products to ensure proper circulation of air. Keep unit away from direct sunlight or other heating source. Keep door closed as often as possible. Be certain cooler is not touching external objects or walls. 		
Excessive noise	 Be certain the cooler is placed on a level surface. Be certain cooler is not touching external objects or walls. 		

Correct Disposal of this product



www.idw.ol

This marking idicates that this product should not be disposed of with other household waste throughout the EU. To prevent possible harm to the environment or human health due to uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collections system, or contact the retailer where the product was purchased for instructions on disposal.









D2. Door Side LED Light

GCG-f CIRCUIT DIAGRAM



A. Evaporator Fan	D1. Interi
B. Power Supply for LED Lights	D2. Door
C1. On/Off Switch for Interior Light	D3. Door
C2. On/Off Switch for Lit Door Logo Light	

SPECIFICATIONS

Model	Volume(L)	Rated Voltage	Climate Class	Rated Current	Lamp Input Power	Refrigerator
G-7F, G-7FB, G-7-FB31N, G-7-F31N	1 56	220-240V /50Hz	4 (30°C,55%)	0.8A	2.1W	R290/70g
GCG-7F, GCG-7FB, GCG-7F2, GCG-7-FB31N* GCG-7-F31N* GCG-7-F231N*					5.7W	

G-7f/GCG-7f

- D1. Interior Top LED Light
- F. Condenser Fan G. Overload for Compressor H. Compressor
- I. Compressor Running Capacitor J. Compressor PTC

Side LED Light

[·] Logo LED Light

- F. Condenser Fan
- G. Overload for Compressor
- I. Compressor Running Capacitor J. Compressor PTC

G

G-7f 220V ELECTRICAL WIRING DIAGRAM





www.idw.glo

GCG-7f 220V ELECTRICAL WIRING DIAGRAM





CONNECTIONS FOR COMPRESSOR

16

G-7f/GCG-7f

CONNECTIONS FOR COMPRESSOR



Innovative DisplayWorks, Inc.

To locate the distributor in your area go to: http://www.idw.global/contact/#distributors